







Part N°: P12

## FITTING INSTRUCTION

- -Remove the hard hose of the air inlet B (see diagram A).
- -Remove the hard hose C.(see diagram A)
- -Do not remove the air inlet A (see diagram A).
- -Place the induction onto the throttle box (see diagram B).
- -The sleeve between the 2 hard hoses of the induction kit enables us to place the GREEN filter behind the air inlet (see diagram B)
- -Plug back the hard hose of the oil vaport recycling into the sleeves of the induction kit provided.





## **IMPORTANT**

The running of your engine is linked directly to the maintenance of the air filter. Clean your air filter every 7000 kms or 4500 miles with GREEN cleaning products.

## WARRANTY

The air filter guarantee is for defects in materials and workmanship only. Guarantee is void if the air filter is damaged by an accident, unreasonable use, neglect, misuse, abuse, improper installation or other causes not arising out of defects in materials and workmanship. The induction kit is a technical product so it is necessary to have some basic mechanical skills. If problems do not hesitate to have your induction kit fitted by a professional.

GREEN Technical Dept: TEL: 00.33.3.44.02.64.64