



KIT ADMISSION DYNAMIQUE DYNAMIC INTAKE KIT

CITROEN ZX 1.9 D 70 HP


S.A.S
Chrono'Sport
122 rue du faubourg Saint Jean
ZA de l'AVELON - 60000 BEAUVAIS -
FRANCE

03.44.02.64.64
03.44.02.87.10

PART N° :DW 10

FITTING INSTRUCTIONS

Depose and delete the original air pipe.(scheme A)
Position the pipe (A) of the kit GREEN to replace the original pipe.(scheme B)
Position the pipe (B) of the kit following the pipe (A) with the provided sleeve.(scheme B)
Fit together the filter TWISTER on the pipe (B) with the provided sleeve.(scheme B)
Position the attaching lug of the kit on the attaching of the original pipe.(scheme B)
Position the filter TWISTER with the provided collar and the attaching lug.(scheme B)
Fit together the case provided in the kit on the filter TWISTER and make it arrive behind the front right bumper.(scheme B)
Fix the case with the provided plastic collar.
To have an efficient stimulation of the TWISTER make a hole of Ø 80mm on the front left shield.(scheme C)
Position the provided bracket in the kit escapade of the case on the shield and fix it with the screw from the kit.
Position the filter TWISTER so that it doesn't touch any mechanical organ.





BE CAREFULL:

To have the best performance of your **TWISTER** the filter must imperatively be stimulated with the case. (scheme C)
Position the **TWISTER** so that it doesn't touch any mechanical organ.

STIMULATION? (Working methods)

The stimulation consists in rising the volume of air in the combustion chamber by a pressure of additional fresh air in the throttle line .
For that you must place the air pipe in front of the vehicle to accelerate the air aspiration.



IMPORTANT

The working of your engine, is directly binded by the maintenance of your air filter. Clean your filter regularly (around 7000 kms) only with the cleaning materials recommended by GREEN.

WARRANTY

Our products are warranted against all manufacturing defect.
Our liability wouldn't be involved in the case of a malfunction due to a bad assembly, or bad use.
The direct admission kit is a technical organ, and requires some car mechanical knowledge.
In the doubt, don't hesitate to entrust the setting of your kit to a professional's care.

Technical service GREEN : TEL: 03.44.02.64.64



Comment utiliser et entretenir votre filtre à air AIR FILTER SERVICE INSTRUCTIONS

Votre filtre à air doit être nettoyé entre 7000 kms et 10000 kms. ou tous les 6 mois.

La périodicité de nettoyage est directement liée à l'environnement dans lequel vous circulez.

Procédure de nettoyage des filtres

UTILISER EXCLUSIVEMENT LES PRODUITS D'ENTRETIEN RECOMMANDÉS PAR GREEN

- Déposer le filtre.
- Souffler le filtre, afin d'évacuer le plus gros des impuretés.
ATTENTION- maintenir la "soufflette" à une distance d'environ 15cm.
- Imprégner le filtre de nettoyant GREEN.
- Laisser agir le produit environ 15 minutes.

- Vous pouvez frotter le filtre à l'aide d'un pinceau
- Rincer le filtre à l'eau CHAUDE, par l'intérieur puis par l'extérieur
- Pour les filtres fortement encrassés, n'hésitez pas à renouveler l'opération.
- Secouer le filtre pour évacuer l'eau.
- Il est possible de se servir d'air comprimé pour évacuer l'eau.
- Faites sécher le filtre sur un radiateur tiède, ou à l'aide d'un sèche-cheveux.
- Vaporiser l'huile GREEN sur toute la surface du filtre, uniformément mais sans excès



How to use and maintain your air filter AIR FILTER SERVICE INSTRUCTIONS

It is essential to oil the GREEN filter using the supplied quantity of oil. Clean your air filter between 7000 km and 10000 km or every 6 months.

Cleaning periodicity is linked directly to the environment in which you drive.

Procedure for cleaning the GREEN filters

USE EXCLUSIVELY THE MAINTENANCE PRODUCTS RECOMMENDED BY GREEN

- Remove the filter
- Blow out the filter to expel the largest impurities
CAUTION: maintain the blower at a distance of 15 cm or so.
- Impregnate the filter with GREEN cleaner
- Allow the product to act for about 15 minutes
- You can rub the filter with a paint brush
- Rinse the filter with hot water first on the inside then on the outside
- For deeply fouled filters, be sure to repeat the operation
- Shake the filter to evacuate the water
- Compressed air can be used to evacuate the water
- Dry the filter on a tepid radiator or using a hair dryer
- Spray GREEN oil onto the entire surface of the filter, uniformly but not excessively

NOMENCLATURE

Article	Référence	Q
FILTRE FILTER	TW 70	1
MANCHON SLEEVE	M2D60	1
MANCHON SLEEVE	M5D60	1
CANALISATION FLEXIBLE PIPE	DUR107	1
CANALISATION FLEXIBLE PIPE	DP25B	1
VIS SCREW	VTH6.25	1
RONDELLE WASHER	RL 06.20	2
ECROU NUT	ECN06	1
PATTE BRACKET	FIX 6	1
COLLIER CLAMP	50/70	3
COLLIER CLAMP	130/150	1
COLLIER CLAMP	70/90	2
VIS SCREW	VTH8.20	1
ECROU NUT	ECN 08	1
RONDELLE WASHER	RP 08	2
COLLIER CLAMP	CL 11420	1
CHAPE ADAPTOR	BR 03	1
GAINÉ ALUMINIUM ALUMINIUM SHEATH	G80TW/1000	1
COLLIER PLASTIQUE PLASTIC CLAMP	CP 360	1



Como utilizar y cuidar su filtro para aire AIR FILTER SERVICE INSTRUCTIONS

Su filtro para aire debe ser limpiado entre los 7000 km y los 10.000 km o cada seis meses.

La periodicidad de limpieza es directamente ligada con el medio ambiente en el que circula usted.

Proceso de limpieza de los filtros

UTILIZAR EXCLUSIVAMENTE LOS PRODUCTOS DE LIMPIEZA RECOMENDADOS POR GREEN

- Depositar el filtro.
- Soplar el filtro a fin de despejar el máximo de impurezas.
CUIDADO: mantener el fuelle a una distancia de unos 15 cm.
- Imprimir el filtro con el producto para la limpieza Green.
- Dejar el producto actuar unos 15 minutos.
- Puede usted frotar el filtro con un pincel.
- Enjuagar el filtro con agua caliente, por el interior y luego por el exterior.
Para los filtros muy ensuciados, no vacile en repetir la operación.
- Sacudir el filtro para quitar el agua.
- Es posible utilizar aire comprimido para quitar el agua.
- Seque usted el filtro en un radiador tibio o utilice un secador.
- Vaporizar el aceite Green en toda la superficie del filtro uniformemente pero sin exeso.

